

HANSON OFFROAD

6951 McDivitt Drive Bakersfield, CA 93313
P:877.757.9779 sales@hansonoffroad.com

CTF38-P TALL CARGO FRAME INSTALLATION

Most Hanson designed cargo packages are built around this tall cargo frame. The small basket (CB38-P) and side platforms (CS7LR-P) mount off of this part.

1. Insert the two aluminum billet inserts into the bottom of the two side posts of the cargo frame.
2. Line up the bolt holes in the posts and the billet inserts. Insert 3/8" bolts and tighten.
3. Insert the two plastic plugs in the ends of the horizontal tube at the top. Use a little silicone to help hold the plugs in place.
4. Place the frame on the tire carrier with basket supports pointing to the rear.
5. Insert the 1/2" bolt through the holes in antenna tabs in the center of the frame, using washers as spacers. Leave a 1/8" gap for tension.
6. Frame is now ready for installing side platforms or baskets.

