

HANSON OFFROAD

6951 McDivitt Drive Bakersfield, CA 93313
P:877.757.9779 sales@hansonoffroad.com

CS7-LR-P SIDE PLATFORM INSTALLATION

These Hanson side platforms mounts to the top of the CTF38-P Tall Cargo Frame.

NOTE: 3M foam tape and aluminum pop rivets are included to mount the aluminum floor to the base of the platforms. The foam tape reduces rattle and the rivets secure the floor for daily driving. Customer will need to drill the necessary holes to install rivets.

1. Hold the driver side platform up to the tall cargo frame with the tallest rail against the tire and the opening facing away from the rear of the jeep.
2. Line up the top hole in the side platform with the hole that is located 4 inches from the top of the cargo frame.
3. Insert a 5/16" bolt and washer and secure with a washer and nut, but do not tighten yet.
4. Line up the bottom hole on the side platform with the lower hole in the cargo frame.
5. Insert 5/16" bolt and washer and secure with a washer and nut and tighten to 20 FT/LBS torque.
6. Go back and tighten other bolt to 20 FT/LBS torque.
7. Repeat steps 1 through 6 to install the passenger side platform.

