

HANSON OFFROAD

12539 Jomani Drive Bakersfield, CA 93312
P:877.757.9779 sales@hansonoffroad.com

TJRP-P / LJRP-P ROCKSLIDER INSTALLATION

Installation of these rockers is fairly straightforward. With the rocker skid positioned correctly in place, clamp to the tub/rocker of the Jeep as shown in the photo below. Once in place, transfer the mount holes and drill 5/16" holes. Complete installation using the supplied hardware.

TJRP-P HARDWARE LIST

5/16" X 1" Carriage Bolt - 16
5/16" Nylock Nut - 16
5/16" Flat Washer - 16

LJRP-P HARDWARE LIST

5/16" X 1" Carriage Bolt - 18
5/16" Nylock Nut - 18
5/16" Flat Washer - 18



1. With rocker skid held in place, transfer and mark all holes along the body for drilling. Also transfer the holes on the underside of the tub as well. The TJRP-P has 3 underneath, the LJRP-P has 4 underneath.



2. Mark the centers of all holes, there will be 7 on the TJRP-P per side and 9 per side on the LJRP-P.



3. Using a 5/16" drill bit, drill out all marked holes through into the tub.



4. Install supplied bolts through the side of the body and up through the tub. Secure on the backside using flat washer and lock nut. Loosely start all bolts before tightening them all down

