

HANSON OFFROAD

12539 Jomani Drive Bakersfield, CA 93312
P:877.757.9779 sales@hansonoffroad.com

XJSP-P: JEEP CHEROKEE (XJ) REAR SIDE PANEL INSTALLATION

1. Hold the side panel in place and mark all holes. These holes will need to be drilled out 3/8" to accept the included rivet nuts. The rivet nut install using the supplied rivet nut tool. With the rivet nut in place on the vehicle, Place rivet nut tool over the rivet nut and thread included socket cap bolt into the rivet nut. Once threaded in, turn the opposing ends of the rivet nut tool to "pull" the rivet nut into the hole. The socket bolt may have to be re-installed to snug the rivet nut on the body. Once all rivet nuts are in place, the side panels can be replaced and installed using supplied hardware.

