

# HANSON OFFROAD

## INSTALLATION INSTRUCTIONS

JZJ1102-P / JZJ1202-P

ZJ FRONT WINCH BUMPER



### PARTS LIST

- 8 - 7/16" X 1.25" Carriage Bolts
- 8 - 7/16" Lock Washers
- 8 - 7/16" Flat Washers
- 8 - 3/8" x 2.5" Bolt
- 8 - 3/8" Lock Washers
- 8 - 3/8" Flat Washer
- 2 - Mounting Brackets

1. Begin with removal of stock front bumper. New hardware and brackets are supplied to mount winch bumper.



2. Mount brackets with tube extensions facing the frame. They are used to offset the brackets when mounting the bumper. Leave brackets loose until bumper is in position.

3. Mount bumper to brackets using supplied carriage bolts. Rotate bumper to properly align with body of vehicle. Tighten all mounting bolts at this time.



HANSON OFFROAD  
6951 MCDIVITT DRIVE BAKERSFIELD CA 93313  
877.757.9779 WWW.HANSONOFFROAD.COM  
SALES@HANSONOFFROAD.COM  
PROUDLY MADE IN THE USA!